

SLUDGE THICKENERS




SLUDGE DRYING BEDS




SLUDGE DRING BEDS




DESIGN MISTAKES BAD SELECTION OF AERATION EQUIPMENT




DESIGN MISTAKES BAD LOCATION FOR MIXERS & LACK OF DIFFUSERS FREE ZONE




AL-BIREH WWTP LAYOUT



AS-SAMRA WWTP LAYOUT



AS-SAMRA WWTP BIOREACTOR CONFIGURATION



SLUDGE DEWATERING

